



LADY

DIMENSIONS (in mm)



Standard execution:



- ↑ 1NO
- ↓ 1NO
- ↕ 2NO P
- ↔ 1NO
- ↔ 2NO P
- ↗ 1NO
- ↘ 1NO
- ↖ 2NO P
- ⏹ 1NC
- ⏹ 2NO P
- ⏹ 1NO
- ⏹ 2NO P
- ⏹ 1NO
- ⏹ 1NO
- ⏹ 2NO P

LADY




STANDARD INTERNATIONAL SYMBOLS FOR PUSH-BUTTONS

Up	Down	Right	Left	Forward	Backward	Rotate Right	Rotate Left	Fast	Slow
HT-LASY-001	HT-LASY-002	HT-LASY-003	HT-LASY-004	HT-LASY-005	HT-LASY-006	HT-LASY-007	HT-LASY-008	HT-LASY-030	HT-LASY-032
HT-LASY-009	HT-LASY-010	HT-LASY-011	HT-LASY-012	HT-LASY-013	HT-LASY-014	HT-LASY-015	HT-LASY-016	HT-LASY-031	HT-LASY-033
HT-LASY-017	HT-LASY-018	HT-LASY-019	HT-LASY-020	HT-LASY-021	HT-LASY-022	HT-LASY-023	HT-LASY-024		
Start	Stop	Start alarm	Alarm	Break	Black button				
HT-LASY-025	HT-LASY-029	HT-LASY-026	HT-LASY-027	HT-LASY-028	HT-LASY-034				



SPARE PARTS



POS	CODE	DESCRIPTION	POS	CODE	DESCRIPTION
1	HT-LASY-XXX	Buttons with international symbols	6	HT-LAKO-001	Switching Element 1NC
2	HT-LAET-006	Rubber gasket for 2 push-buttons with ring		HT-LAKO-002	Switching Element 2NC Simultaneous
3	HT-LAET-002	Mushroom head emergency stop button (without push-button element)		HT-LAKO-003	Switching Element 1NO
4	HT-LAET-008	Suspension hanger		HT-LAKO-004	Switching Element 1NO + 1NC
	HT-LA02-000	Empty Enclosure Set* (2 buttons)		HT-LAKO-005	Switching Element 2NO Progressive
	HT-LA03-000	Empty Enclosure Set* (3 buttons)		HT-LAKO-006	Switching Element 2NO Simultaneous
	HT-LA04-000	Empty Enclosure Set* (4 buttons)	7	HT-LAET-009	2÷4 buttons pendant station rubber sleeve
5	HT-LA05-000	Empty Enclosure Set* (5 buttons)		HT-LAET-010	5÷12 buttons pendant station rubber sleeve
	HT-LA06-000	Empty Enclosure Set* (6 buttons)	8	HT-LAET-013	Mechanical interlock
	HT-LA08-000	Empty Enclosure Set* (8 buttons)			
	HT-LA010-000	Empty Enclosure Set* (10 buttons)			
	HT-LA012-000	Empty Enclosure Set* (12 buttons)			

Set*: incl. cover, bottom, sealings, screws e.g.