FRS

DIMENSIONS (in mm)

2 Contacts:





B-COMMAND PREMIUM ENGINEERING
GRUETZMUEHLENWEG 46
DE-22339 HAMBURG
T. +49 40-538092-50
F. +49 40-538092-85
INFO@B-COMMAND.COM
WWW.B-COMMAND.COM

FRS

DIMENSIONS (in mm)

3 Contacts:





FRS

DIMENSIONS (in mm)

4 Contacts:





FRS

DIMENSIONS (in mm)

2 Contacts with flange:







FRS

DIMENSIONS (in mm)

3 Contacts with flange:





B-COMMAND PREMIUM ENGINEERING
GRUETZMUEHLENWEG 46
DE-22339 HAMBURG
T. +49 40-538092-50
F. +49 40-538092-85
INFO@B-COMMAND.COM
WWW.B-COMMAND.COM

FRS

DIMENSIONS (in mm)

4 Contacts with flange:







FRS

DIMENSIONS (in mm)

2 Contacts with flexible shaft:





FRS

DIMENSIONS (in mm)

3 Contacts with flexible shaft:





FRS

DIMENSIONS (in mm)

4 Contacts with flexible shaft:





FRS

DIMENSIONS (in mm)

2 Contacts with Male Connection:







FRS

DIMENSIONS (in mm)

3 Contacts with Male Connection:





FRS

DIMENSIONS (in mm)

4 Contacts with Male Connection: